

Need Help - Use Bookmarks on the left side.

Brand	Models	Gal.	Input	Fuel	Vent	1 st Hr	E.F.	Dia.	Ht.	Tank	Parts
<p style="text-align: center;">'N'=Nat, 'P'=LP ↑ Size-Inches ↑ 1st Hour Rating Gal. ↑ Energy Factor</p>											
<u>TALL 30 GALLON</u>											
AWHC*	<u>FG61-30T30-3NOV</u>	30	30	N1	3	54	0.61	16	59 3/4	6-Year	6-Year
Lochinvar	ETN030	30	32	N3	3	51	0.58	16	59 1/4	6-Year	6-Year
Lochinvar	LTN030	30	32	N3	3	51	0.58	16	59 1/4	6-Year	6-Year
Lochinvar*	<u>LTN030G</u>	30	32	N2	3	55	0.61	16	59 1/8	6-Year	6-Year
Lochinvar	STN030	30	32	N3	3	51	0.58	16	59 1/4	9-Year	9-Year
Lochinvar	XTN030	30	32	N3	3	51	0.58	16	59 1/4	9-Year	9-Year
Lochinvar*	<u>XTN030G</u>	30	32	N2	3	55	0.61	16	59 1/8	10-Year	6-Year
<u>TALL 40 GALLON</u>											
Lochinvar*	<u>LTN040G</u>	40	34	N2	3	63	0.54	18	59 1/2	6-Year	6-Year
Lochinvar	ETN040	40	34	N3	3	62	0.56	18	59 1/2	6-Year	6-Year
Lochinvar	LTN040	40	34	N3	3	62	0.56	18	59 1/2	6-Year	6-Year
Lochinvar	ETN040-3	40	40	N3	3	72	0.56	18	61 1/4	6-Year	6-Year
Lochinvar	LTN040-3	40	40	N3	3	72	0.56	18	61 1/4	6-Year	6-Year
AWHC*	<u>FG61-40T40-3NOV</u>	40	40	N1	3	69	0.59	18	62	6-Year	6-Year
Lochinvar*	<u>LTN041G</u>	40	40	N2	3	75	0.59	18	59 3/8	6-Year	6-Year
AWHC*	<u>FG62-40T40-3NOV</u>	40	40	N1	3	69	0.63	20	62	6-Year	6-Year
Lochinvar*	<u>LTN040G-4</u>	40	48	N2	4	86	0.59	18	60 3/4	6-Year	6-Year
Lochinvar	ETN040-4	40	50	N3	4	80	0.55	18	61 1/2	6-Year	6-Year
Lochinvar	LTN040-4	40	50	N3	4	80	0.55	18	61 1/2	6-Year	6-Year
Lochinvar*	<u>XTN040G</u>	40	34	N2	3	63	0.54	18	59 1/2	9-Year	9-Year
Lochinvar	STN040	40	34	N3	3	62	0.56	18	59 1/2	9-Year	9-Year
Lochinvar	XTN040	40	34	N3	3	62	0.56	18	59 1/2	9-Year	9-Year
Lochinvar	STN040-3	40	40	N3	3	72	0.56	18	61 1/4	9-Year	9-Year
Lochinvar	XTN040-3	40	40	N3	3	72	0.56	18	61 1/4	9-Year	9-Year
AWHC*	<u>FG91-40T40-3NOV</u>	40	40	N1	3	69	0.59	18	62	9-Year	9-Year
Lochinvar*	<u>XTN041G</u>	40	40	N2	3	75	0.59	18	59 3/8	10-Year	6-Year
Lochinvar*	<u>XTN040G-4</u>	40	48	N2	4	86	0.59	18	60 3/4	10-Year	6-Year
Lochinvar	STN040-4	40	50	N3	4	80	0.55	18	61 1/2	9-Year	9-Year
Lochinvar	XTN040-4	40	50	N3	4	80	0.55	18	61 1/2	9-Year	9-Year
AWHC*	<u>FG122-40T40-3NOV</u>	40	40	N1	3	69	0.63	20	62	12-Year	12-Year

N1 Propane, change 'N' to 'P' in model number.

N2 Propane, change 'N' to 'L' in model number. 2006 Gas - Lochinvar

N3 Propane, change 'N' to 'L' in model number.

Indicates additional letters or numbers.

*FVIR Compliant

Need Help - Use Bookmarks on the left side.

Brand	Models	Gal.	Input	Fuel	Vent	1 st Hr	E.F.	Dia.	Ht.	Tank	Parts
<p style="text-align: center;">'N'=Nat, 'P'=LP ↑ Size-Inches ↑ 1st Hour Rating Gal. ↑ Energy Factor</p>											
<u>TALL 50 GALLON</u>											
Lochinvar	ETN050	50	40	N3	3	80	0.55	20	60 1/4	6-Year	6-Year
Lochinvar	LTN050	50	40	N3	3	80	0.55	20	60 1/4	6-Year	6-Year
AWHC*	<u>FG61-50T40-3NOV</u>	50	40	N1	3	80	0.58	20	60 3/4	6-Year	6-Year
Lochinvar*	<u>LTN050G</u>	50	40	N2	3	86	0.58	20	59 5/8	6-Year	6-Year
AWHC*	<u>FG62-50T40-3NOV</u>	50	40	N1	3	80	0.62	22	60 3/4	6-Year	6-Year
Lochinvar*	<u>LTN050G-4</u>	50	48	N2	4	92	0.58	20	58 1/2	6-Year	6-Year
Lochinvar	ETN050-4	50	50	N3	4	86	0.54	20	60 1/4	6-Year	6-Year
Lochinvar	LTN050-4	50	50	N3	4	86	0.54	20	60 1/4	6-Year	6-Year
AWHC*	<u>FG61-50T50-4NOV</u>	50	50	N1	4	87	0.58	20	60 3/4	6-Year	6-Year
AWHC*	<u>FG62-50T50-4NOV</u>	50	50	N1	4	87	0.60	22	60 3/4	6-Year	6-Year
Lochinvar	ETN051	48	65	N3	4	87	0.55	22	61 1/4	6-Year	6-Year
Lochinvar	LTN051	48	65	N3	4	87	0.55	22	61 1/4	6-Year	6-Year
Lochinvar*	<u>LTN051G</u>	48	65	N2	4	101	0.59	22	59 1/4	6-Year	6-Year
Lochinvar	STN050	50	40	N3	3	80	0.55	20	60 1/4	9-Year	9-Year
Lochinvar	XTN050	50	40	N3	3	80	0.55	20	60 1/4	9-Year	9-Year
AWHC*	<u>FG91-50T40-3NOV</u>	50	40	N1	3	80	0.58	20	60 3/4	9-Year	9-Year
Lochinvar*	<u>XTN050G</u>	50	40	N2	3	86	0.58	20	59 5/8	10-Year	6-Year
Lochinvar*	<u>XTN050G-4</u>	50	48	N2	4	92	0.58	20	58 1/2	10-Year	6-Year
Lochinvar	STN050-4	50	50	N3	4	86	0.54	20	60 1/4	9-Year	9-Year
Lochinvar	XTN050-4	50	50	N3	4	86	0.54	20	60 1/4	9-Year	9-Year
Lochinvar	STN051	48	65	N3	4	87	0.55	22	61 1/4	9-Year	9-Year
Lochinvar	XTN051	48	65	N3	4	87	0.55	22	61 1/4	9-Year	9-Year
Lochinvar	XDN050	47	65	N3	4	87	0.55	22	61 1/4	9-Year	9-Year
Lochinvar*	<u>XTN051G</u>	48	65	N2	4	101	0.59	22	59 1/4	10-Year	6-Year
AWHC*	<u>FG122-50T40-3NOV</u>	50	40	N1	3	80	0.62	22	60 3/4	12-Year	12-Year
AWHC*	<u>FG122-50T50-4NOV</u>	50	50	N1	4	87	0.60	22	60 3/4	12-Year	12-Year
<u>TALL 65 GALLON</u>											
Lochinvar	ETN065	65	65	N3	4	120	0.50	22	64 1/2	6-Year	6-Year
Lochinvar	<u>ETN065G</u>	65	65	N2	4	126	0.55	22	64 1/2	6-Year	6-Year
Lochinvar	STN065	65	65	N3	4	120	0.50	22	64 1/2	9-Year	9-Year
Lochinvar	<u>STN065G</u>	65	65	N2	4	126	0.55	22	64 1/2	10-Year	6-Year

N1 Propane, change 'N' to 'P' in model number.

N2 Propane, change 'N' to 'L' in model number. 2006 Gas - Lochinvar

N3 Propane, change 'N' to 'L' in model number.

Indicates additional letters or numbers.

*FVIR Compliant

Need Help - Use Bookmarks on the left side.

Brand	Models	Gal.	Input	Fuel	Vent	1 st Hr	E.F.	Dia.	Ht.	Tank	Parts
<p style="text-align: center;">'N'=Nat, 'P'=LP ↑ Size-Inches ↑ 1st Hour Rating Gal. ↑ Energy Factor</p>											
<u>TALL 75 GALLON</u>											
Lochinvar	ETN075	75	75	N3	4	130	0.50	24 1/2	63 3/4	6-Year	6-Year
AWHC	<u>G62-75T75-4NO</u>	75	75.1	N	4	NA	NA	26	63 1/2	6-Year	6-Year
AWHC	<u>G62-75T75-4NV</u>	75	75.1	N1	4	NA	NA	26	63 1/2	6-Year	6-Year
Lochinvar	<u>ETN076</u>	75	76	N2	4	NA	NA	24 1/2	63 3/4	6-Year	6-Year
Lochinvar	ETN076	75	76	N3	4	NA	NA	24 1/2	63 3/4	6-Year	6-Year
Lochinvar	STN075	75	75	N3	4	130	0.50	24 1/2	63 3/4	9-Year	9-Year
Lochinvar	<u>STN076</u>	75	76	N2	4	NA	NA	24 1/2	63 3/4	10-Year	6-Year
Lochinvar	STN076	75	76	N3	4	NA	NA	24 1/2	63 3/4	9-Year	9-Year
AWHC	<u>G122-75T75-4NV</u>	75	75.1	N1	4	NA	NA	26	63 1/2	12-Year	12-Year
<u>TALL 100 GALLON</u>											
AWHC	<u>G62-100T77-4NV</u>	100	77	N1	4	NA	NA	28	68 1/2	6-Year	6-Year
Lochinvar	<u>ETN100</u>	100	85	N2	4	NA	NA	28 1/4	68 3/4	6-Year	6-Year
Lochinvar	<u>STN100</u>	100	85	N2	4	NA	NA	28 1/4	68 3/4	10-Year	6-Year
<u>SHORT 30 GALLON</u>											
Lochinvar	LSN030	30	30	N3	3	52	0.57	18	48 1/4	6-Year	6-Year
Lochinvar	ESN030	30	30	N2	3	54	0.57	18	48 1/4	6-Year	6-Year
AWHC*	<u>FG61-30S30-3NOV</u>	30	30	N1	3	54	0.61	18	49	6-Year	6-Year
Lochinvar*	<u>LSN030G</u>	30	30	N2	3	54	0.61	18	48 3/8	6-Year	6-Year
Lochinvar	XSN030	30	30	N3	3	52	0.57	18	48 1/4	9-Year	9-Year
Lochinvar	SSN030	30	30	N2	3	54	0.57	18	48 1/4	10-Year	6-Year
Lochinvar*	<u>XSN030G</u>	30	30	N2	3	54	0.61	18	48 3/8	10-Year	6-Year
<u>SHORT 40 GALLON</u>											
Lochinvar	ESN040	40	34	N3	3	62	0.56	20	50 1/4	6-Year	6-Year
Lochinvar	LSN040	40	34	N3	3	62	0.56	20	50 1/4	6-Year	6-Year
Lochinvar	ESN040-3	40	40	N2	3	73	0.56	20	51	6-Year	6-Year
Lochinvar	LSN040-3	40	40	N3	3	73	0.56	20	51	6-Year	6-Year
AWHC*	<u>FG61-40S40-3NOV</u>	40	40	N1	3	67	0.59	20	52 1/4	6-Year	6-Year
Lochinvar*	<u>LSN041G</u>	40	40	N2	3	72	0.59	20	50	6-Year	6-Year
AWHC*	<u>FG62-40S40-3NOV</u>	40	40	N1	3	67	0.62	22	52 1/4	6-Year	6-Year
Lochinvar	SSN040	40	34	N3	3	62	0.56	20	50 1/4	9-Year	9-Year
Lochinvar	XSN040	40	34	N3	3	62	0.56	20	50 1/4	9-Year	9-Year
Lochinvar	SSN040-3	40	40	N2	3	73	0.56	20	51	10-Year	6-Year
Lochinvar	XSN040-3	40	40	N3	3	73	0.56	20	51	9-Year	9-Year
AWHC*	<u>FG91-40S40-3NOV</u>	40	40	N1	3	67	0.59	20	52 1/4	9-Year	9-Year
Lochinvar*	<u>XSN041G</u>	40	40	N2	3	72	0.59	20	50	10-Year	6-Year

N1 Propane, change 'N' to 'P' in model number.

N2 Propane, change 'N' to 'L' in model number. 2006 Gas - Lochinvar

N3 Propane, change 'N' to 'L' in model number.

Indicates additional letters or numbers.

*FVIR Compliant

Need Help - Use Bookmarks on the left side.

Brand	Models	Gal.	Input	Fuel	Vent	1 st Hr	E.F.	Dia.	Ht.	Tank	Parts
<p style="text-align: center;">'N'=Nat, 'P'=LP ↑ Size-Inches ↑ 1st Hour Rating Gal. ↑ Energy Factor</p>											
<u>SHORT 50 GALLON</u>											
AWHC*	<u>FG61-50S40-3NOV</u>	50	40	N1	3	88	0.58	22 3/4	54 1/4	6-Year	6-Year
<u>POWER VENT [40 GAL]</u>											
Lochinvar	<u>DVN041</u>	40	40	N2	2/3	72	0.62	20	58 1/2	6-Year	6-Year
AWHC*	<u>PVG62-40T42-3NV</u>	40	42	N1	2/3	70	0.62	20	67 1/2	6-Year	6-Year
AWHC	<u>PVG62-40T50-3NV</u>	40	50	N1	3	72	0.62	20	69	6-Year	6-Year
Lochinvar	<u>SVN041</u>	40	40	N2	2/3	72	0.62	20	58 1/2	10-Year	6-Year
<u>POWER VENT [50 GAL]</u>											
Lochinvar	<u>DVN051</u>	48	40	N2	2/3	85	0.62	22	58 1/2	6-Year	6-Year
AWHC*	<u>PVG62-50T42-3NV</u>	50	42	N1	2/3	70	0.62	22	66 1/4	6-Year	6-Year
AWHC*	<u>PVG62-50T60-3NV</u>	50	60	N1	3	95	0.62	22	66 1/4	6-Year	6-Year
AWHC	<u>PVG62-50T63-3NHV</u>	50	63	N1	3	95	0.60	22	70	6-Year	6-Year
Lochinvar	<u>DVN052</u>	48	65	N2	3/4	105	0.64	22	63 1/4	6-Year	6-Year
Lochinvar	<u>SVN051</u>	48	40	N2	2/3	85	0.62	22	58 1/2	10-Year	6-Year
Lochinvar	<u>SVN052</u>	48	65	N2	3/4	105	0.64	22	63 1/4	10-Year	6-Year
<u>POWER VENT [65 GAL]</u>											
Lochinvar	<u>DVN065</u>	65	65	N2	3/4	124	0.62	22	66 3/4	6-Year	6-Year
Lochinvar	<u>SVN065</u>	65	65	N2	3/4	124	0.62	22	66 3/4	10-Year	6-Year
<u>POWER VENT [75 GAL]</u>											
AWHC	<u>PVG62-75T75-3NV</u>	75	75.1	N1	3	NA	NA	26	70 1/4	6-Year	6-Year
Lochinvar	<u>DVN076</u>	75	76	N2	3/4	NA	NA	26	66	6-Year	6-Year
Lochinvar	<u>SVN076</u>	75	76	N2	3/4	NA	NA	26	66	10-Year	6-Year
<u>POWER DIRECT VENT [40 GAL]</u>											
AWHC*	<u>PDVG62-40T42-3NV</u>	40	42	N1	2/3	67	0.63	20	67 1/2	6-Year	6-Year
<u>POWER DIRECT VENT [50 GAL]</u>											
AWHC*	<u>PDVG62-50T42-3NV</u>	50	42	N1	2/3	78	0.63	22	66 1/4	6-Year	6-Year
Lochinvar	<u>PRN050</u>	48	60	N2	3/4	105	0.62	22	79	6-Year	6-Year
AWHC*	<u>PDVG62-50T60-3NV</u>	50	60	N1	3	95	0.63	22	66 1/4	6-Year	6-Year
Lochinvar	<u>SRN050</u>	48	60	N2	3/4	105	0.62	22	79	10-Year	6-Year
<u>POWER DIRECT VENT [65 GAL]</u>											
Lochinvar	<u>PRN065</u>	65	65	N2	3/4	120	0.60	22	81 7/8	6-Year	6-Year
Lochinvar	<u>SRN065</u>	65	65	N2	3/4	120	0.60	22	81 7/8	10-Year	6-Year
<u>POWER DIRECT VENT [75 GAL]</u>											
Lochinvar	<u>PRN075</u>	75	70	N2	3/4	140	0.59	26	81 7/8	6-Year	6-Year
Lochinvar	<u>SRN075</u>	75	70	N2	3/4	140	0.59	26	81 7/8	10-Year	6-Year

N1 Propane, change 'N' to 'P' in model number.

N2 Propane, change 'N' to 'L' in model number. 2006 Gas - Lochinvar

N3 Propane, change 'N' to 'L' in model number.

Indicates additional letters or numbers.

*FVIR Compliant

Need Help - Use Bookmarks on the left side.

Brand	Models	Gal.	MBtu Input	Fuel	Vent	1 st Hr	E.F.	Dia.	Ht.	Warranty Tank	Warranty Parts
<p style="text-align: center;">'N'=Nat, 'P'=LP ↑ Size-Inches ↑ 1st Hour Rating Gal. ↑ Energy Factor</p>											
<u>MOBILE HOME SEALED [30 GAL]</u>											
Lochinvar	MDN030	30	30	P	3	51	0.57	16	56 1/4	6-Year	6-Year
AWHC	MHSCG51-30T30-3PV	30	30	P	3	52	0.61	16	57 1/2	5-Year	5-Year
Lochinvar	MDN030G	30	30	P	3	52	0.61	16	57 3/8	6-Year	6-Year
Lochinvar	SDN030G	30	30	P	3	52	0.61	16	57 3/8	10-Year	6-Year
<u>MOBILE HOME SEALED [40 GAL]</u>											
AWHC	MHSCG51-40T30-3PV	40	30	P	3	59	0.59	18	58	5-Year	5-Year
Lochinvar	MDN040G	40	30	P	3	59	0.59	18	57 7/8	6-Year	6-Year
Lochinvar	SDN040G	40	30	P	3	59	0.59	18	57 7/8	10-Year	6-Year
<u>MOBILE HOME STD.[30 GAL]</u>											
AWHC	MHG61-30T31-3PV	30	31	P	3	53	0.61	16	59 3/4	6-Year	6-Year
<u>MOBILE HOME STD.[40 GAL]</u>											
AWHC	MHG61-40T31-3PV	40	31	P	3	60	0.59	18	60 3/4	6-Year	6-Year
<u>DIRECT VENT [40 GAL]</u>											
AWHC*	DVG62-40S38-NV	40	38	N1	NA	60	0.59	22	65 1/4	6-Year	6-Year
Lochinvar	BFN040G	40	38	N2	NA	71	0.59	20	63 1/4	6-Year	6-Year
Lochinvar	SFN040G	40	38	N2	NA	71	0.59	20	63 1/4	10-Year	6-Year
<u>DIRECT VENT [50 GAL]</u>											
AWHC*	DVG62-50T42-NV	50	42	N1	NA	70	0.58	22	73 1/2	6-Year	6-Year
Lochinvar	BFN050G	50	42	N2	NA	88	0.58	20	72 1/4	6-Year	6-Year
Lochinvar	SFN050G	50	42	N2	NA	88	0.58	20	72 1/4	10-Year	6-Year

N1 Propane, change 'N' to 'P' in model number.

N2 Propane, change 'N' to 'L' in model number. 2006 Gas - Lochinvar

N3 Propane, change 'N' to 'L' in model number.

Indicates additional letters or numbers.

*FVIR Compliant