

Installation Instructions for Electric Thermostats

⚠ WARNING



Electrical Shock Hazard
Disconnect power before servicing.
Replace all parts and panels before operating.
Failure to do so can result in death or electrical shock.

⚠ WARNING



Water temperature over 125°F can cause severe burns instantly or death from scalds. Children, disabled and elderly are at highest risk of being scalded.
See instructions manual before setting temperature at water heater.
Feel water before bathing or showering.
Temperature limiting valves are available.

Important: Follow your water heater manufacturer's instruction manual for complete installation instructions.

Typical wiring diagrams included in package.

1. Turn off electrical supply to the water heater.
2. Remove front access cover plate and insulation to expose the thermostat.
3. Verify wiring configuration and identify wires with the wiring diagram.
4. Remove cover from over the thermostat. Mark and remove wires from thermostat.
5. Slide thermostat from behind mounting bracket.
6. Install new thermostat under mounting bracket. Be certain thermostat fits flat against tank surface.
7. Reconnect wires under screw heads according to diagram provided with the water heater.
8. Tighten connections firmly.
9. Set thermostat to desired temperature. If thermostat has a RED reset button, push in.
10. **Important:** Replace removed thermostat plastic or cardboard cover.
11. Replace insulation and front access cover plate on water heater.
12. Following the water heater manufacturer's instructions, turn on the electrical supply to water heater.

ELECTRIC THERMOSTATS

